

An Australian invention has defeated the butt joint...

The RebateMate™ is a revolutionary power tool designed to cut rebates along the edges of both plasterboard and cement sheet in preparation for jointing.

RebateMate™ is simple to use and delivers substantial cost and time savings while producing excellent results every time. This unique tool eliminates butt joints and the problems commonly associated with them including joint weakness, glancing light, peaking, cracking, visible joints and wastage.

The RebateMate™ attaches to most commercial vacuums creating a safe and relatively dust free work environment.

JOIN THE REVOLUTION, ELIMINATE BUTT JOINTS WITH THE REBATEmate™



...and, it's got people talking!

"The tool is simple and easy to use and the results were excellent."

"The RebateMate™ is the tool of the future, solving butt joint problems completely."

"I was simply amazed at the performance of this tool and the bonus of no dust floating around - what a breakthrough."

"Over the years I have seen many changes and developments in our industry, this machine solves one of the major problems that the industry has had to put up with for the last 50 years BUTT JOINTS."

"The time and cost savings were enormous and the onsite architects were very impressed with the final results."

"RebateMate™ has a broad impact across our trade and creates savings at every task."

"The RebateMate™ worked perfectly, it eliminated all unsightly peaking."



REBATEmate™

Instructions...

INSTRUCTIONS FOR PLASTERBOARD

1. Secure plasterboard on a flat even surface
2. Attach vacuum pipe to tool exhaust cover
3. Rest the edge of flat guide plate on edge of sheet
4. Holding the grip handle turn the tool on
5. Push the tool fully into material under protective paper
6. Guide the tool along the length of sheet (left to right) to create rebate
7. Lift paper
8. Use a brush to apply full coverage of RebateMate™ adhesive to the two exposed surfaces (underside of paper and exposed plaster)
9. Use joint knife to firmly re-apply paper to sheet edge
10. Allow two hours before jointing



INSTRUCTIONS FOR CEMENT SHEET

1. Secure cement sheet on a flat even surface
2. Attach vacuum pipe to tool exhaust cover
3. Rest the edge of flat guide plate on edge of sheet with wheel above sheet surface
4. Holding the grip handle turn the tool on
5. Push the tool down into the cement sheet surface
6. Guide the tool along the length of sheet (left to right) to create rebate
7. Repeat with second run to ensure correct depth and clean edges



Product Information:

Code	Description	Barcode
RM-T	RebateMate™	9315778000451
RM-D	RebateMate™ Cutting Disc	9315778000468
RM-G	RebateMate™ Adhesive	9315778000475

Australian Patent. International Innovation Patent Pending.

WATCH IT OPERATING 

NOTES

- Only RebateMate™ Adhesive is approved for use with the RebateMate system
- Refer to RebateMate™ Instruction Manual for full operating instructions

REBATEmate™



Ph: 1300 653 177 | Fx: 1300 657 442
 International Ph: 61 7 5535 7655 | International Fx: 61 7 5535 7741
 Sales Email: sales@wallboardtools.com.au www.wallboardtools.com.au

